Xhorse®

Toyota Highlander

Support more models

Toyota Corolla、Camry、Levin、RAV etc.,

VVDI



KEY TOOL MAX & MINI OBD

①Please update device to latest version for this function



During the process don't insert the key, please keep ignition off

① Disconnect the positive pole of the car battery to protect the connector and avoid short circuits

② Please connect to fuse box as the image



J3 lock plug



③ Please connect the ELV wires as shown



J5 lock plug

④ Please connect to car OBD, all key lost cables and car battery

J4 lock plug

J6 lock plug

J6 lock plug

⑤ Please generate start chip referring to software interface



⑥ Please disconnect all cables,recover all connection wires as car original status

If the connection wires not recovery to original status and start the car directly, the fuse boxe and device will be burnt

⑦ Test generated transponder